

Kvaser REST API Specification

Copyright 2011-2015 Kvaser AB, Mölndal, Sweden
<http://www.kvaser.com>

Printed Thursday 21st May, 2015

We believe that the information contained herein was accurate in all respects at the time of printing. Kvaser AB cannot, however, assume any responsibility for errors or omissions in this text. Also note that the information in this document is subject to change without notice and should not be construed as a commitment by Kvaser AB.

(This page is intentionally left blank.)

Contents

1 About this Manual	4
2 Introduction	5
3 Connection Functions	6
3.1 deviceStatus	6
3.2 canInitializeLibrary	7
3.3 canUnloadLibrary	7
4 CANlib Equivalent Functions	9
4.1 canOpenChannel	9
4.2 canClose	9
4.3 canSetBusParams	10
4.4 canBusOn	10
4.5 canBusOff	11
4.6 canSetBusOutputControl	11
4.7 canRead	11
4.8 canWrite	12
4.9 canIoCtl	13
5 Connection flow examples	14
6 Document Revision History	18

1 About this Manual

This document specifies the JSON REST API that is available in selected Kvaser CAN interfaces. The reader is assumed to be familiar with Kvaser CANlib.



THIS SPECIFICATION IS SUBJECT TO CHANGE!

2 Introduction

This document specifies the JSON REST API which is available in selected Kvaser CAN interfaces. The API is based upon the Kvaser CANlib, so most function and parameter names are the same. Assuming that the device is connected, has IP address 192.168.1.10, and is listening on port 8080, you can access the API in the form:

`http://192.168.1.10:8080/deviceStatus`

The following rules applies to this API:

- All constants must be specified with its numerical value, e.g. `canBITRATE_1M` should be given as `-1`
- All numbers are decimal
- All calls can take an optional integer parameter, `ident=` which is included in the response

The status constants that are currently used by the JSON REST API are listed in Table 1.

Constant	Value
<code>canOK</code>	0
<code>canERR_PARAM</code>	-1
<code>canERR_NOMSG</code>	-2
<code>canERR_NOCHANNELS</code>	-5
<code>canERR_TIMEOUT</code>	-7
<code>canERR_INVHANDLE</code>	-10
<code>canERR_NOT_IMPLEMENTED</code>	-32
<code>canERR_INVALID_PASSWORD</code> ¹	-128
<code>canERR_NO SUCH FUNCTION</code> ¹	-129
<code>canERR_NOT_AUTHORIZED</code> ¹	-130
<code>canERR_INVALID_SESSION</code> ¹	-131

Table 1: Status constants used by the JSON REST API. Note that the last constants are extensions to current Kvaser CANlib.

¹Extensions to current Kvaser CANlib.

3 Connection Functions

The following functions are used to query and connect to a device. This is done differently than in Kvaser CANlib, e.g. the session concept is new.

3.1 deviceStatus

You may at any time ask a device for its status with the function `deviceStatus`. The device can then respond whether it is free or already connected to some host.

- `uri:/deviceStatus`

- parameters:

[mode=jsonp] If set, the response will be coded in JSONP, i.e. wrapped with the fixed string 'canlib_callback(...)'.

- returns:

```
"usage" : %u,           # Flags: 0=Free, 1=In use via service,  
                      # 2=In use via JSON API,  
                      # 4=In use via JSONP API  
  
# The following response codes are only present if the device  
# is in use:  
"timeout" : %u,          # time left before current session  
                      # will end (seconds)  
"ip" : "%u.%u.%u.%u"   # IP address of the host the device  
                      # is currently connected to.
```

- example:

```
http://192.168.1.10:8080/deviceStatus?mode=jsonp  
  
canlib_callback({"usage":1})  
  
http://192.168.1.10:8080/deviceStatus?mode=jsonp&ident=0001  
  
canlib_callback({"usage":0, "ident":1})  
  
http://192.168.1.10:8080/deviceStatus  
  
{"usage":1}  
  
http://192.168.1.10:8080/deviceStatus  
  
{"usage":3, "timeout":1066, "ip":"192.168.1.12"}
```

3.2 canInitializeLibrary

The function `canInitializeLibrary` sets up a connection and creates a session. Therefore, this routine must be called before any other function that needs a session. When a session is active, the device will deny any further calls to this function by returning status code -131 (Invalid session).

The returned session must be used when calling other functions, denoted with `<session>` below. A session is terminated either by an explicit call to `canUnloadLibrary` or after an inactivity of more than 'timeout' seconds.

- `uri:/canInitializeLibrary`

- parameters:

[**password=%s**] Access password, the string can be URI encoded if needed.

[**mode=jsonp**] When set, the response will be coded as JSONP.

[**timeout=%u**] The session timeout in seconds.

[**dummy_session=%u**] If set to '1', the session returned will be '00000000000000000000000000000000'.

- returns:

```
{"stat":<canOK | canERR_xxx>, "session": "%32x"}
```

- example:

```
http://192.168.1.10:8080/canInitializeLibrary?timeout=1200
{"stat":0, "session": "1b6ed79f755f0ab94ff9ad62470ad0a0"}
http://192.168.1.10:8080/canInitializeLibrary?timeout=1200
{"stat": -131}
```

3.3 canUnloadLibrary

The function `canUnloadLibrary` terminates an active session, making the device free.

- uri: /<session>/canUnloadLibrary

- parameters: None.

- returns:

```
{"stat":<canOK | canERR_xxx>}
```

- example:

```
http://192.168.1.10:8080/1b6ed79f755f0ab94ff9ad62470ad0a0/
    canUnloadLibrary
```

```
{"stat":0}
```

4 CANlib Equivalent Functions

The following functions mirror functions in Kvaser CANlib. Please refer to the CANlib documentation for further information about these functions and their parameters.

Note that all constants must be specified with their decimal numerical values, e.g. canBITRATE_1M should be given as -1. All return values will also be returned as decimal integers, e.g. canOK will be returned as 0.

4.1 canOpenChannel

The function canOpenChannel returns a handle to the opened channel. This handle should be passed in other functions as the hnd parameter as needed.

- uri:<session>/canOpenChannel
- parameters:
 - channel=%u** Channel number on the device.
 - flags=%u** Flags according to canOPEN_xxx.
- returns:

```
{"stat":<canOK | canERR_xxx>, "hnd":%d}
# hnd is only valid if stat returns canOK
```
- example:

```
http://192.168.1.10:8080/1b6ed79f755f0ab94ff9ad62470ad0a0/
    canOpenChannel?channel=0&flags=8

{"stat":0, "hnd":0}
```

4.2 canClose

- uri:<session>/canClose
- parameters:
 - hnd=%u**
- returns:

```
{"stat":<canOK | canERR_xxx>}
```
- example:

```
http://192.168.1.10:8080/1b6ed79f755f0ab94ff9ad62470ad0a0/
    canClose?hnd=0

{"stat":0}
```

4.3 canSetBusParams

- uri:<session>/canSetBusParams

- parameters:

hnd=%u

freq=%d Bit rate, or one of canBITRATE_xxx. If freq is not any of canBITRATE_xxx, the following parameters must also be set:

tseg1=%u

tseg2=%u

sjw=%u

noSamp=%u

- returns:

```
{"stat":<canOK | canERR_xxx>}
```

- example:

```
http://192.168.1.10:8080/1b6ed79f755f0ab94ff9ad62470ad0a0/
    canSetBusParams?hnd=0&freq=-1&ident=1234
```

```
{"stat":0, "ident":1234}
```

4.4 canBusOn

- uri:<session>/canBusOn

- parameters:

hnd=%u

- returns:

```
{"stat":<canOK | canERR_xxx>}
```

- example:

```
http://192.168.1.10:8080/1b6ed79f755f0ab94ff9ad62470ad0a0/
    canBusOn?hnd=0
```

```
{"stat":0}
```

4.5 canBusOff

- uri:<session>/canBusOff

- parameters:

hnd=%u

- returns:

{"stat":<canOK | canERR_xxx>}

- example:

```
http://192.168.1.10:8080/1b6ed79f755f0ab94ff9ad62470ad0a0/
    canBusOff?hnd=0
```

{"stat":0}

4.6 canSetBusOutputControl

- uri:<session>/canSetBusOutputControl

- parameters:

hnd=%u

drivertype=%u Driver type according to canDRIVER_xxx.

- returns:

{"stat":<canOK | canERR_xxx>}

- example:

```
http://192.168.1.10:8080/1b6ed79f755f0ab94ff9ad62470ad0a0/
    canSetBusOutputControl?hnd=0&drivertype=4
```

{"stat":0}

4.7 canRead

- uri:<session>/canRead

- parameters:

hnd=%u

max=%u Max number of messages to be received in the answer, default is 1.

- returns:

```
{"stat":<canOK | canERR_xxx>,
 "msgs": [
 {
   "id": %u,
   "dlc": %u,
   "time": %u,
   "flag": %u,
   "msg": [%u, ...]
 },
 ...
 ]}
```

- example:

```
192.168.1.10:8080/1b6ed79f755f0ab94ff9ad62470ad0a0/canRead?
hnd=0&max=5

{"stat":0, "msgs":[
 {"id":10, "dlc":4, "msg":[67,12,8,0], "time":3520517614, "flag":2},
 {"id":12, "dlc":3, "msg":[32,12,16], "time":3520517724, "flag":2},
 {"id":14, "dlc":4, "msg":[0,0,24,0], "time":3520517835, "flag":2}]}]
```

4.8 canWrite

- uri:<session>/canWrite

- parameters:

hnd=%u

id=%u

flag=%u

dlc=%u

msg=%u[,%u[...]]

- returns:

```
{"stat":<canOK | canERR_xxx>}
```

- example:

```
http://192.168.1.10:8080/1b6ed79f755f0ab94ff9ad62470ad0a0/
    canWrite?hnd=0&id=55&flag=0&msg
    =99,100,101,102,103,104,105&dlc=7

{"stat":0}
```

4.9 canIoCtl

- uri:<session>/canIoCtl

- parameters:

hnd=%u

func=%u Function according to canIOCTL_xxx.

buf=%s Parameter depending on the actual function used.

- returns:

```
{"stat":<canOK | canERR_xxx>}
```

- example:

```
http://192.168.1.10:8080/1b6ed79f755f0ab94ff9ad62470ad0a0/
    canIoCtl?hnd=0&func=10

{"stat":0}
```

5 Connection flow examples

This chapter contains a number of flow examples.

- Successful log in, Figure 1.
- Unsuccessful log in, Figure 2.
- Log in, send a CAN message and clean up, Figure 3 on Page 15.
- Invalid channel, Figure 4 on Page 16.
- Read CAN messages (messages available), Figure 5 on Page 16.
- Read CAN messages (no messages available), Figure 6 on Page 17.
- Error examples, Figure 7 on Page 17.




Figure 1: Successful log in




Figure 2: Unsuccessful log in



Figure 3: Log in, send a CAN message and clean up



Figure 4: Invalid channel




Figure 5: Read CAN messages (messages are available)


Read CAN messages (messages no available)

Figure 6: Read CAN messages (no messages are available)


Error examples

Figure 7: Error examples

6 Document Revision History

Version history for document IN_98151_kvaser_rest_api_specification:

Revision	Date	Changes
-	2013-09-23	Initial version
	2013-11-28	Changed layout of references, figures.
1	2014-08-19	Minor updates. First public version.
1.1	2014-10-02	Added description of dummy_session.